Reversing the door

1. Using a sharp object pry out the two plug buttons on the top of the unit. Save the plugs for later use.
2. Remove the upper hinge cover.
3. Remove the two Phillips screws that connect the upper hinge to the cabinet.
4. Carefully lift the door, placing it on a padded surface to avoid scratching.
5. Tilt the unit back and remove the screws on the lower hinge.
6. Remove the stationary leg and attach to the opposite side.
7. Attach the lower hinge on the opposite side.
8. Place the door on the lower hinge making sure that the hinge pin goes into the door bushing.
9. Place the upper hinge cover on the top of the door and loosely place the screws in the top of the cabinet.
10. Line up the door and tighten the screws.

(Check the seal around the door for air gaps. Use a hair dryer to heat the gasket and expand the seal to fill in the gaps)