
TOP LOAD CYCLE & FABRIC CARE GUIDE

Built-in sensors use AI technology to select the right wash/dry motions, temperatures and more for advanced fabric care. Or, choose from a wide range of custom wash and dry cycles.



Get a fast start by choosing one of the pre-loaded wash and dry cycles.

PRE-LOADED CYCLES

WASH CYCLES	CYCLE DESCRIPTION
Normal	Mixed loads and cotton or linen fabrics
AI Wash	Optimizes cycle based on contents of laundry
Bedding	Bulky items, pillows, blankets or comforters
Quick Wash	Lightly soiled clothing or small loads
Heavy Duty	Heavily soiled laundry, especially cotton fabrics
Deep Wash	Adds additional water for heavily soiled items
Waterproof	Water-resistant clothing or mattress covers

PRE-LOADED CYCLES

DRY CYCLES	CYCLE DESCRIPTION
Normal	Mixed loads and cotton or linen fabrics
Quick Dry	Small loads
Heavy Duty	Extra drying for heavier fabrics
Bedding	Bulky items, pillows, blankets or comforters
AI Dry	Optimizes cycle based on fabrics
Delicates	Lingerie, sheer or easily damaged fabrics
Perm. Press	Minimizes wrinkles in "wrinkle-free" fabrics

Or, quickly and easily customize your laundry with special cycles for a wide range of load types.

DOWNLOADABLE CYCLES

WASH CYCLES	CYCLE DESCRIPTION
Delicates*	Lingerie, sheer or easily damaged fabrics
Baby Wear	Designed for lightly soiled baby clothing
Dresses	Lightly soiled, delicate dresses
Econowash	Helps reduce normal cycle energy consumption
Overnight Wash	Helps reduce spin noise and wrinkling
Single Item	Quickly washes a single item
Swimwear	Gently removes chlorine or salt from swimwear
Small Load	A small number of normally soiled items
Large Load	Washer is approximately half full
X Large Load	Washer is very full

DOWNLOADABLE CYCLES


DRY CYCLES	CYCLE DESCRIPTION
Antibacterial*	A high-temperature dry cycle
Towels	Designed for towels
Super Dry	Thoroughly dries cotton fabrics
Jeans	Designed specifically for jeans
Blanket Refresh	Warms and fluffs up blankets
Low Temp Dry	Reduces energy consumption
Overnight Dry	Energy efficient cycle dries a small load overnight
Easy Ironing	Leaves clothes slightly damp for easy ironing
Small Load	Small or light items
Large Load Dry	Dryer is approximately half full
X Large Load Dry	Dryer is very full
Wrinkle Prevention	Prevents wrinkles by tumbling clothes after the cycle
Rack Dry	Dries items that should not be tumbled (install the rack)

*Indicates default downloaded cycle.

Sleek electronic controls let you dial in just the right cycle while the LED display shows remaining cycle time and settings at a glance.

GET LAUNDRY DAY DIALED IN—IT'S EASY

Built-in intelligence makes laundry less of a chore by taking out the guesswork.



1 POWER IT ON

Touch Power to turn on your LG washer or dryer—you'll be greeted with a tune.

2 TURN THE DIAL

Rotate the dial to choose from 7 pre-loaded cycles or select Downloaded to access additional cycles.

3 PRESS START

Touch and hold Start to begin the selected cycle. After sensing the load, the display will show remaining cycle time.

COMPLETELY CUSTOMIZE YOUR CYCLE

Modify any cycle by using the touch panel to change settings like temperature, spin speed or dry level to your liking. You can also add available options or select extra functions.

MODIFY ANY CYCLE

Press pads such as Temp., Spin or Dry Level to make adjustments to the selected cycle before you hit Start.

ADD OTHER OPTIONS

Available options for each cycle such as Extra Rinse or Wrinkle Care will light up on the touch panel—simply press to add.