
LG WASHTOWER™ CYCLE & FABRIC CARE GUIDE

Built-in sensors use AI technology to select the right wash motions, temperatures and more for advanced fabric care. Or, choose from a wide range of custom wash and dry cycles.



Get a fast start by choosing one of the pre-loaded wash and dry cycles.

PRE-LOADED CYCLES

WASH CYCLES	CYCLE DESCRIPTION
Normal*	Mixed loads and cotton or linen fabrics
Bedding	Bulky items, pillows, blankets or comforters
Delicates	Lingerie, sheer or easily damaged fabrics
Heavy Duty	Heavily soiled laundry, especially cotton fabrics
Quick Wash	Lightly soiled clothing or small loads
Tub Clean	Designed to clean the inside of the washer

PRE-LOADED CYCLES

DRY CYCLES	CYCLE DESCRIPTION
Normal	Mixed loads and cotton or linen fabrics
Bedding	Bulky items, pillows, blankets or comforters
Delicates	Lingerie, sheer or easily damaged fabrics
Heavy Duty	Extra drying for heavier fabrics
Small Load	Small or light items
Dry Time	Lets you manually select the drying time
Condenser Care	Additional condenser cleaning

Or, quickly and easily customize your laundry with special cycles for a wide range of load types.

DOWNLOADABLE CYCLES

WASH CYCLES	CYCLE DESCRIPTION
Small Load	A small number of normally soiled items
Cold Wash	Washes with cold water for better energy efficiency
Rinse+Spin**	Rinses and spins items only
Sweat Stains	Helps remove sweat stains and odors
Single Garment	Quickly washes a single item
Minimize Residue	Adds a rinse for enhanced rinsing performance
Baby Wear	Powerful rinse helps remove stains from baby clothes
Spin Only	Drains and spins with no wash or rinse
Perm. Press	Minimizes wrinkles in "wrinkle-free" fabrics
Hand Wash/Wool	Shrinkable wool or hand-washable items
Sportswear	Special or treated fabrics for sports or outerwear
Sanitary	Washes clothes at a high temperature
Allergiene®	Reduces certain allergens using heat and steam

DOWNLOADABLE CYCLES

DRY CYCLES	CYCLE DESCRIPTION
Blanket	Dries bulky blankets
Blanket Refresh	Warms and fluffs up blankets
Rainy Days	Dries damp clothes
Single Garment	Quickly dries a single item

DOWNLOADABLE CYCLES


DRY CYCLES	CYCLE DESCRIPTION
Deodorization	Helps reduce odors in clothes that don't need washing
Lingerie	Specifically designed to dry lingerie
Easy Ironing	Leaves clothes slightly damp for easy ironing
Super Dry	Thoroughly dries cotton clothes
Economic Dry	Uses low temperatures to dry clothes and save energy
Big Size Item	Designed to dry bulky items
Minimize Wrinkles	Helps prevent wrinkles after drying
Shoes/Fabric Doll	Refreshes shoes or stuffed toys (install the rack)
Full Size Load	Dries large amounts of clothes
Perm. Press**	Minimizes wrinkles in "wrinkle-free" fabrics
Wool	Shrinkable wool or hand-washable items
Sportswear	Special or treated fabrics for sports or outerwear
Towels	Designed for towels
Power Dry	A high-temperature dry cycle
Rack Dry	Dries items that should not be tumbled (install the rack)
Air Dry	Tumble dries heat-sensitive items
Drum Care	Use regularly to prevent odors

*Optimizes cycle based on fabrics using AI.
**Indicates default downloaded cycle.

Only LG WashTower™ has the convenient Center Control® panel that's perfectly positioned with both washer and dryer controls at just the right height.

INTUITIVE, EASY-REACH CONTROLS

Built-in intelligence makes laundry less of a chore by taking out the guesswork.



1 POWER IT ON

Touch Power to turn on the washer or dryer—both can run at the same time but need to be set separately.

2 SELECT YOUR CYCLE

Choose from the pre-loaded wash and dry cycles or touch Downloaded to edit or add cycles via the ThinQ® app.

3 PRESS START

Touch and hold Start to begin the selected cycle. After sensing the load, the display will show remaining cycle time.

COMPLETELY CUSTOMIZE YOUR CYCLE

Modify any cycle by using the touch panel to change settings like temperature, spin speed or dry level to your liking. You can also add available options or select extra functions.

MODIFY ANY CYCLE

Press pads such as Temp., Spin or Dry Level to make adjustments to the selected cycle before you hit Start.

ADD OTHER OPTIONS

Available options for each cycle such as Extra Rinse or Wrinkle Care will light up on the touch panel—simply press to add.

Energy Saver	Very Normal	70 • • • 30	More Time	Less Time
Normal	Damp		Wrinkle Care	Condenser Care
Dry Mode	Dry Level	Dry Time		
*Wi-Fi	*Remote	*Control Lock	*Drum Light	
Hot • • • Cold	High • • • No Spin	Heavy Normal Light	Steam *Tub Clean	TurboWash
Temp.	Spin	Soil	Extra Rinse	Pre-wash
*Wi-Fi	*Remote	*Control Lock	*Drum Light	