
FABRIC SOFTENER DISPENSER INSTALLATION INSTRUCTIONS


Kit Contains:
1 Fabric Softener Dispenser
1 Instruction Sheet

1. Remove the agitator cap



Insert a flat blade screwdriver into the channel between the agitator cap and the agitator body, and twist or press down on the screwdriver to loosen the agitator cap.

2. Insert the fabric softener dispenser




Insert the fabric softener dispenser into the top of the agitator and push down to lock it into place.

©Whirlpool Corporation 2015
(All Rights Reserved)

INSTRUCTIONS D'INSTALLATION DU DISTRIBUTEUR D'ASSOUPLISSANT POUR TISSU


Contenu de l'ensemble :
1 distributeur d'assouplissant pour tissu
1 fiche d'instructions

1. Retirer le capuchon de l'agitateur



Insérer un tournevis à lame plate dans la rainure entre le capuchon de l'agitateur et le corps de l'agitateur, et tourner ou pousser vers le bas sur le tournevis pour desserrer le capuchon de l'agitateur.

2. Insérer le distributeur d'assouplissant pour tissu



Insérer le distributeur d'assouplissant pour tissu dans le sommet de l'agitateur et pousser vers le bas pour verrouiller en place.

©Whirlpool Corporation 2015
(tous droits réservés)