Pedestal Installation Instructions

Models: PED12W, PED12B

Compatible with models: FF712W, FF712WLHD, FF713B, FF713BLHD

What's Included:

- Pedestal
- Bracket (1)

Properly mounting the refrigerator on the pedestal as instructed below will raise your appliance to a more accessible height and help prevent it from tipping forward.


Important: A minimum of two people is required to safely lift and mount the unit onto the pedestal.

Note: Mount the refrigerator onto the pedestal only after the pedestal is securely positioned in its final location.

Instructions:

1. Remove all the packaging from the pedestal and ensure the preassembled brackets are attached properly.
2. Place the pedestal in its designated final position and adjust the leveling feet as needed.
3. Secure the bottom bracket to the floor using hardware rated for your specific flooring material (fasteners are not included).
4. Position the refrigerator over the front lip of the pedestal and slide the compressor plate beneath the rear bracket prongs.

Back of Refrigerator:



If you need help with your installation, call our Customer Service facility at **800-932-4267** (**Ext. 513**) between 9:00 AM and 5:00 PM ET or visit our website **summitappliance.com/support** at any time. We will do our best to answer your questions.

To order replacement parts, visit our website: **summitappliancepartsparts.com**